



User Manual

Service Mode

1. Open the oven door and press "3" for 5 seconds to enter Service Mode.
2. "SERVICE" will be displayed.
3. To check the number of times the door has been opened or closed, press the number "3". The LED will display the times.
4. To clear this number, press number "4". "4-CLEAR" will be displayed. Press the green "START/CONFIRM" button and "CLEARED" will be displayed. The message will be cancelled.
5. Press the red "STOP/RESET" button to enter Door Open Mode.
6. Close the door to enter Ready Mode.

Restore Factory Default Settings

1. In Power Up or Ready Mode, press the green "START/CONFIRM" and "0" buttons simultaneously to Restore Factory Defaults.

CARE AND CLEANING

- **To avoid electrical shock which can cause severe personal injury or death, unplug power cord or open circuit breaker to oven before cleaning or removing light bulb.**

- Cleaning the interior and exterior will require a mild detergent, water and a soft sponge or cloth.
- Do not use cleaners that include ammonia or citrus.
- Do not use water pressure cleaning systems on your microwave.
- Inspect air vents monthly and clean using a damp cloth.

TROUBLESHOOTING

COMPLAINT	POSSIBLE CAUSE	REMEDY
Dim oven light	Cooking at low power level	This is normal
Steam forms on oven door	When cooking foods in a microwave steam is generated.	This is normal
Hot air expelled from vents	Foods cooking in a microwave may release heat	This is normal
Oven does not start	Power cord not plugged in correctly	Plug cord into outlet correctly
	Fuse blown or circuit breaker open	Replace fuse (should be repaired by authorized servicer) or reset breaker
	Malfunctioning outlet	Test outlet with other electrical appliance
	Door not closed	Close door

- This warranty is effective from the time of purchase.
- This warranty is not effective if damage occurs because of accident, carelessness, improper installation, lack of proper set – up, supervision when required or if the equipment is installed or operated in any manner contrary to the installation and operating instructions.
- Work performed by unauthorized personnel or unauthorized service agencies voids this Warranty
- This warranty does not apply to, and Solwave is not responsible for any warranty claims on products sold or used outside of the contiguous United States.
- This equipment is intended for commercial use only. Warranty is void if equipment is installed in anything other than commercial applications.